



## **CSI-1**Charge Status Indicator

- Monitors battery charger voltage and current
- Alarms if voltage AND current are insufficient
- Adjustable limit value for voltage
- Current limit value is 1 Amp
- N.O. and N.C. relay outputs
- Range is 8 to 30 Vdc
- Monitored voltage is used for power
- Detachable connector

## MICRO-AIDE

